

## Acrylit Installation Guide:

### Cutting:

Panels can be cut using power or hand saws.

Saw blades should be fine-toothed carbide tipped or safety fabric reinforced abrasive disc. Face shields and appropriate safety equipment should be worn by all operators. Some typical installation details are shown at the left.

### Drilling:

All panels should be pre-drilled not less than 1-1/2" from the panel end, and the holes drilled a minimum of 1/16" larger than the fastener diameter. Panels can be drilled singly or several at a time.

### Fasteners:

When possible, fasteners should be installed at high points of the corrugation with spacing of 6" on center for intermediate purlins and siding applications.

### Installation:

Under no circumstances should panels be allowed to support undistributed loads such as the weight of a human body. Use only approved roof ladders for installation.